

SF MODEL FURNACES

Use this chart to determine the correct core replacement.

IF YOU HAVE THIS MODEL	ORDER THIS REPLACEMENT CORE
SF-20	CORE
2324	STOCK #: 2605A MODEL #: RP-20Q
2381	
SF-20Q	CORE
2382	STOCK #: 2605A MODEL #: RP-20Q
2385	
2386	
SF-20F	CORE
2329	STOCK #: 2606A MODEL #: RP-20FQ
SF-20FQ	CORE
2389	STOCK #: 2606A MODEL #: RP-20FQ
2465	
SF-25	CORE
2320	STOCK #: 2607A MODEL #: RP-30Q
2325	
SF-25Q	CORE
2383	STOCK #: 2607A MODEL #: RP-30Q
2387	
SF-25F	CORE
2330	STOCK #: 2608A MODEL #: RP-30FQ
SF-25FQ	CORE
2390	STOCK #: 2608A MODEL #: RP-30FQ
2467	

IF YOU HAVE THIS MODEL	ORDER THIS REPLACEMENT CORE
SF-30	CORE
2321	STOCK #: 2607A MODEL #: RP-30Q
2326	
2376	
SF-30Q	CORE
2384	STOCK #: 2607A MODEL #: RP-30Q
2388	
2481	
2488	
SF-30F	CORE
2331	STOCK #: 2608A MODEL #: RP-30FQ
SF-30FQ	CORE
2391	STOCK #: 2608A MODEL #: RP-30FQ
2469	
2484	
SF-35	CORE
2322	STOCK #: 2609A MODEL #: RP-35Q
2327	
SF-35Q	CORE
2398	STOCK #: 2609A MODEL #: RP-35Q
2414	
SF-35F	CORE
2302	STOCK #: 2610A MODEL #: RP-35FQ
2332	
SF-35FQ	CORE
2400	STOCK #: 2610A MODEL #: RP-35FQ

IF YOU HAVE THIS MODEL	ORDER THIS REPLACEMENT CORE
SF-42	CORE
2323	STOCK #: 2609A MODEL #: RP-35Q
2328	
SF-42Q	CORE
2399	STOCK #: 2609A MODEL #: RP-35Q
2415	
2415	
2482	
SF-42F	CORE
2333	STOCK #: 2610A MODEL #: RP-35FQ
SF-42FQ	CORE
2401	STOCK #: 2610A MODEL #: RP-35FQ